



Einhell

EXPERT PLUS



Cordless Hedge Trimmer
GE-CH 1846 Li Kit (1x2,0Ah)

Item No.: 3410683

Ident No.: 11027

Bar Code: 4006825615432

The GE-CH 1846 Li Kit cordless hedge trimmer is an efficient tool which thanks to its low weight and handy size provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. With the new Power X-Change battery system from Einhell, the hedge trimmer has an 18 V battery pack with 2.0 Ah for long work sessions.

Features & Benefits

- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- Small and easy to handle
- Low weight for user-friendly operation
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover on cutters
- Bumper guard with holder for wall mount
- Blades made of laser-cut and diamond-ground steel
- Sturdy cutter guard for storage and transportation




Technical Data

- Max. running time	80 min
- Charging time	40min
- Blade length	520 mm
- Cutting length	460 mm
- Spacing between teeth	15 mm
- Cuts per minute	2200 min ⁻¹
- Accumulator	18 V 2000 mAh Li-Ion
- Number of accumulators	1 Pieces

Logistic Data

- Product weight	2.3
- Gross weight single packaging	3.4 kg
- Dimensions single packaging	907 x 175 x 180 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	14 kg
- Dimensions Export Carton	940 x 380 x 270 mm
- Container quantity (20"/40"/40"HC)	1152 2368 2664
- Product weight	2.3 kg



Available as special accessories



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 30min Power-X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory