

<b>1</b>	<b>APPLICATION</b> .....	<b>3</b>
<b>2</b>	<b>DESCRIPTION (FIG. A)</b> .....	<b>3</b>
<b>3</b>	<b>PACKAGE CONTENT LIST</b> .....	<b>3</b>
<b>4</b>	<b>SYMBOLS</b> .....	<b>3</b>
<b>5</b>	<b>GENERAL POWER TOOL SAFETY WARNINGS</b> .....	<b>4</b>
5.1	<i>Working area</i> .....	4
5.2	<i>Electrical safety</i> .....	4
5.3	<i>Personal safety</i> .....	4
5.4	<i>Power tool use and care</i> .....	5
5.5	<i>Service</i> .....	5
<b>6</b>	<b>SPECIFIC SAFETY WARNINGS</b> .....	<b>5</b>
<b>7</b>	<b>ASSEMBLY</b> .....	<b>5</b>
7.1	<i>Mounting the swivel castors</i> .....	5
7.2	<i>Mounting the hose</i> .....	6
7.3	<i>Fitting and removing the motor housing</i> .....	6
7.4	<i>Fitting the dust bag</i> .....	6
7.5	<i>Mounting the tube to the hose</i> .....	6
<b>8</b>	<b>OPERATION</b> .....	<b>6</b>
8.1	<i>Switching on and off</i> .....	6
8.2	<i>Vacuuming up waste material</i> .....	6
8.3	<i>Vacuuming up dust released from an electrical tool</i> .....	6
8.4	<i>Vacuuming up liquids</i> .....	6
8.5	<i>Blowing</i> .....	6
8.6	<i>Emptying the tub</i> .....	6
<b>9</b>	<b>CLEANING AND MAINTENANCE</b> .....	<b>7</b>
9.1	<i>Cleaning</i> .....	7
9.2	<i>Cleaning the tub</i> .....	7
9.3	<i>Cleaning the dust filter</i> .....	7
<b>10</b>	<b>TECHNICAL DATA</b> .....	<b>7</b>
<b>11</b>	<b>SERVICE DEPARTMENT</b> .....	<b>7</b>

12	STORAGE .....	8
13	WARRANTY .....	8
14	ENVIRONMENT .....	8
15	DECLARATION OF CONFORMITY .....	9

# VACUUM CLEANER WET/DRY 1000W 15L POWX322

## 1 APPLICATION

Your wet/dry cleaner has been designed for vacuuming up dry waste material and dust, as well as for vacuuming up liquids. It is not designed for commercial use.



**WARNING! Read this manual and general safety instructions carefully before using the appliance, for your own safety. Your power tool should only be passed on together with these instructions.**

## 2 DESCRIPTION (FIG. A)

- |                           |                                     |
|---------------------------|-------------------------------------|
| 1. On/off switch          | 9. Handle with air valve            |
| 2. Motor housing          | 10. Tube                            |
| 3. Handgrip motor housing | 11. Wet & Dry floor brush           |
| 4. Clamp                  | 12. 2 in 1 brush                    |
| 5. Tub                    | 13. Dust bag                        |
| 6. Hose connection        | 14. Dirt filter                     |
| 7. Swivel castor          | 15. Hose connection (blow function) |
| 8. Hose                   |                                     |

## 3 PACKAGE CONTENT LIST

- Remove all packing materials.
- Remove remaining packaging and transit supports (if existing).
- Check the completeness of the packing content.
- Check the appliance, the power cord, the power plug and all accessories for transportation damages.
- Keep the packaging materials as far as possible till the end of the warranty period. Dispose it into your local waste disposal system afterwards.



**WARNING: Packing materials are no toys! Children must not play with plastic bags! Danger of suffocation!**

1x vacuum cleaner  
1x manual  
1x bag  
1x hose  
1x Wet & Dry floor brush

1x 2 in 1 brush  
4x swivel castor  
1x Dirt filter  
3x Tube



**When parts are missing or damaged, please contact your dealer.**

## 4 SYMBOLS

In this manual and/or on the machine the following symbols are used:

	Denotes risk of personal injury or damage to the tool.		Class II - The machine is double insulated; Earthing wire is therefore not necessary.
	Read the manual carefully before use.		In accordance with essential requirements of the European directive(s).

## **5 GENERAL POWER TOOL SAFETY WARNINGS**

Read all safety warnings and all instructions. Failure to follow all heed warnings and follow instructions may result in electric shock, fire and/or serious injury. Keep safety warnings and instructions for future reference. The term "power tool" in the safety warnings refers to your mains- operated (corded) power tool or battery- operated (cordless) power tool.

### **5.1 Working area**

- Keep working area clean and well lit. Untidy and dark areas can lead to accidents.
- Do not operate power tools in potentially explosive surroundings, for example, in the presence of inflammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders at a distance when operating a power tool. Distractions can cause you to lose control of it.

### **5.2 Electrical safety**



**Always check that the power supply corresponds to the voltage on the rating plate.**

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use adapter plugs with earthed power tools. Unmodified plugs and matching outlets will reduce the risk of an electric shock.
- Avoid body contact with earthed surfaces such as pipes, radiators, kitchen ranges and refrigerators. There is an increased risk of an electric shock if your body is earthed.
- Do not expose power tools to rain or wet conditions. If water gets inside a power tool, it will increase the risk of an electric shock.
- Do not damage the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep the cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of an electric shock.
- When operating a power tool outdoors, use an extension cable suitable for outdoor use. Using a cord suitable for outdoor use reduces the risk of an electric shock.
- If operating a power tool in a damp location is unavoidable, use a power supply protected by a residual current device (RCD). Using an RCD reduces the risk of an electric shock.

### **5.3 Personal safety**

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool when you are tired or under the influence of drugs, alcohol or medication. A moment of inattention when operating a power tool may result in serious personal injury.
- Use safety equipment. Always wear eye protection. Using safety equipment such as a dust mask, non-skid safety shoes, a hard hat, or hearing protection whenever it is needed will reduce the risk of personal injury.
- Avoid accidental starts. Ensure the switch is in the off position before inserting the plug. Carrying power tools with your finger on the switch or plugging in power tools when the switch is in the on position makes accidents more likely.
- Remove any adjusting keys or spanners before turning on the power tool. A spanner or key left attached to a rotating part of the power tool may result in personal injury.
- Do not reach out too far. Keep your feet firmly on the ground at all times. This will enable you retain control over the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from the power tool. Loose clothes, jewellery or long hair can become entangled in the moving parts.

- If there are devices for connecting dust extraction and collection facilities, please ensure that they are attached and used correctly. Using such devices can reduce dust-related hazards.

#### **5.4 Power tool use and care**

- Do not expect the power tool to do more than it can. Use the correct power tool for what you want to do. A power tool will achieve better results and be safer if used in the context for which it was designed.
- Do not use the power tool if the switch cannot turn it on and off. A power tool with a broken switch is dangerous and must be repaired.
- Disconnect the plug from the power source before making adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store power tools, when not in use, out of the reach of children and do not allow people who are not familiar with the power tool or these instructions to operate it. Power tools are potentially dangerous in the hands of untrained users.
- Maintain power tools. Check for misalignment or jammed moving parts, breakages or any other feature that might affect the operation of the power tool. If it is damaged, the power tool must be repaired. Many accidents are caused by using poorly maintained power tools.
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to jam and are easier to control.
- Use the power tool, accessories and cutting tools, etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work which needs to be done. Using a power tool in ways for which it was not intended can lead to potentially hazardous situations.

#### **5.5 Service**

- Your power tool should be serviced by a qualified specialist using only standard spare parts. This will ensure that it meets the required safety standards.

### **6 SPECIFIC SAFETY WARNINGS**

- Do not vacuum up highly inflammable liquids, acids or thinners.
- Do not vacuum up water at a temperature above 60 °C.
- Do not vacuum up toxic substances.
- Never vacuum up dry waste material or dust without dust filter in place.
- Check whether the dust filter has been removed when using the machine for vacuuming up liquids.
- If you use an extension cord, it must be of a watertight construction.
- Do not jam the air inlet mouth.
- Do not collect combustible and explosive objects such as glowing cigarettes, gasoline, etc.
- Do not collect sharp objects
- Do not collect objects which can easily attach on the filter such as calcareousness powder and graphite powder. Because those will block the ventilation and damage the motor.
- Do not overturn the machine, in case water goes into the motor and damages the motor.

### **7 ASSEMBLY**

#### **7.1 Mounting the swivel castors**

- Remove the motor housing.
- Turn the tub (5) upside down and insert the swivel castors (7) in the openings. Push the wheels in the foreseen openings, so that it forms a square like shape.
- Turn the tub upright again.
- Re-fit the motor housing.

**7.2 Mounting the hose**

- Insert the hose (8) in the connection (6) and press it on firmly.

**7.3 Fitting and removing the motor housing**

- The motor housing has been locked to the tub with clamps.
- To remove the motor housing (3). First remove the clamps (6) and then lift it from the tub (7).
- To re-fit the motor housing, place it on the tub and tighten the clamps.

**7.4 Fitting the dust bag**

A dust bag is suitable for collecting small waste material and dust.

- Remove the motor housing (3).
- Suspend the dust bag in the tub.
- Re-fit the motor housing.

**7.5 Mounting the tube to the hose**

- Slide the tube on the handgrip (9).
- Place the required nozzle on the tail end of the tube.

**8 OPERATION**

Make sure the power cord has been fully unwound before you switch on the machine. The air leaving the grids must not be hindered.

When using the machine in combination with an electrical tool, switch on the machine first and then the electrical tool.

**8.1 Switching on and off**

- To switch the machine on, set the on/off switch (1) to "I".
- To switch the machine off, set the on/off switch (1) to "0".

**8.2 Vacuuming up waste material**

- Check whether the dust bag (13) has been fitted.
- Mount the Wet & Dry floor brush (11) to the tube (10).

**8.3 Vacuuming up dust released from an electrical tool**

- Check whether the dust bag (13) has been fitted.
- Connect the hose with the handgrip (9) directly to the dust extraction outlet of the electrical tool.

**8.4 Vacuuming up liquids**

- Check whether the dust bag (13) has been removed.
- Make sure the inside of the tub (7) is clean and free from dust.
- Mount the dirt filter (14)
- Mount the tube (10) to the handgrip of the hose (9).

**8.5 Blowing**

- You can also use this tool to blow away dust, leaves etc. Disconnect the hose from the hose connection (6) on the side of the tub and connect the hose to the special connection for the blow function (15) on top of the tool.

**8.6 Emptying the tub**

- Switch off and unplug the machine.
- Remove the motor housing (3).
- Empty the tub (7).

## **9 CLEANING AND MAINTENANCE**



**Attention! Before performing any work on the equipment, pull the power plug.**

### **9.1 Cleaning**

- Keep the ventilation slots of the machine clean to prevent overheating of the engine.
- Regularly clean the machine housing with a soft cloth, preferably after each use.
- Keep the ventilation slots free from dust and dirt.
- If the dirt does not come off use a soft cloth moistened with soapy water.



**Never use solvents such as petrol, alcohol, ammonia water, etc. These solvents may damage the plastic parts.**



**Do not submerge the motor housing in water!**

### **9.2 Cleaning the tub**

- Empty and clean the tub (7) after each use.
- Dry the tub carefully after the machine has been used for vacuuming up liquids.

### **9.3 Cleaning the dirt filter**

- Shake out the dust from the dirt filter (14) after each use.

## **10 TECHNICAL DATA**

	<b>POWX322</b>
Rated Voltage	220-240 V
Rated Frequency	50 Hz
Rated Power	1000 W
Tank capacity	15 L
Cable length	3,5 m
Suction power	16kPa
Tank material	Stainless steel
Motor quantity	1
Tank size	280 x 250mm
Blowing function	Yes
Tube type	3 pieces
Hose length	1,5 m
Vacuum type	Dry & wet

## **11 SERVICE DEPARTMENT**

- Damaged switches must be replaced by our after-sales service department.
- If the connecting cable (or mains plug) is damaged, it must be replaced by a special connecting cable which is available from our service department. Replacement of the connecting cable should only be carried out by our service department (see last page) or by a specialist (qualified electrician).

## 12 STORAGE

- Thoroughly clean the whole machine and its accessories.
- Store it out of the reach of children, in a stable and secure position, in a cool and dry place, avoid too high and too low temperatures.
- Protect it from exposure to direct sunlight. Keep it in the dark, if possible.
- Don't keep it in plastic bags to avoid humidity build-up.

## 13 WARRANTY

- This product is warranted as provided by law for a 36 -month period effective from the date of purchase by the first user.
- This warranty covers all material or production flaws excluding : batteries, chargers, defective parts subject to normal wear & tear such as bearings, brushes, cables, and plugs, or accessories such as drills, drill bits, saw blades, etc. ; damage or defects resulting from maltreatment, accidents or alterations; nor the cost of transportation.
- Damage and/or defects resulting from inappropriate use also do not fall under the warranty provisions.
- We also disclaim all liability for any bodily injury resulting from inappropriate use of the tool.
- Repairs may only be carried out by an authorised customer service centre for Powerplus tools.
- You can always obtain more information at the number 00 32 3 292 92 90.
- Any transportation costs shall always be borne by the customer, unless agreed otherwise in writing.
- At the same time, no claim can be made on the warranty if the damage of the device is the result of negligent maintenance or overload.
- Definitely excluded from the warranty is damage resulting from fluid permeation, excessive dust penetration, intentional damage (on purpose or by gross carelessness), inappropriate usage (use for purposes for which the device is not suitable), incompetent usage (e.g. not following the instructions given in the manual), inexperienced assembly, lightning strike, erroneous net voltage. This list is not exhaustive.
- Acceptance of claims under warranty can never lead to the prolongation of the warranty period nor commencement of a new warranty period in case of a device replacement.
- Devices or parts which are replaced under the warranty therefore remain the property of Varo NV.
- We reserve the right to reject a claim whenever the purchase cannot be verified or when it is clear that the product has not been properly maintained. (Clean ventilation slots, carbon brushes serviced regularly, etc.).
- Your purchase receipt must be kept as proof of date of purchase.
- Your appliance must be returned undismantled to your dealer in an acceptably clean state, (in its original blow-moulded case if applicable to the unit), accompanied by proof of purchase.

## 14 ENVIRONMENT



Should your appliance need replacement after extended use, do not dispose of it with the household refuse, but in an environmentally safe way.

Waste produced by electrical machine items should not be handled like normal household rubbish. Please recycle where recycle facilities exist. Check with your Local Authority or retailer for recycling advice.



**15 DECLARATION OF CONFORMITY**



**varo**

**VARO N.V. - Vic. Van Rompuy N.V.**- Joseph Van Instraat 9 - BE2500 Lier - BELGIUM,  
declares that,

Product:	Vacuumcleaner Wet/Dry
Trade mark:	POWERplus
Model:	POWX322

is in conformity with the essential requirements and other relevant provisions of the applicable European Directives, based on the application of European harmonized standards. Any unauthorized modification of the apparatus voids this declaration.

European Directives (including, if applicable, their amendments up to the date of signature):

2011/65/EU  
2014/35/EU  
2014/30/EU

European harmonized standards (including, if applicable, their amendments up to the date of signature):

EN60335-1 : 2012  
EN60335-2-2 : 2010  
EN55014-1 : 2017  
EN55014-2 : 2015  
EN61000-3-2 : 2014  
EN61000-3-3 : 2013

Keeper of the Technical Documentation: Philippe Vankerkhove, VARO – Vic. Van Rompuy N.V.

The undersigned acts on behalf of the company CEO,

Philippe Vankerkhove  
Regulatory Affairs – Compliance Manager  
Lier, 21/02/2020